



Powerchimp Portable Charger

Comes pre-charged

- Ready to use instant power wherever you are
- Pocket size - big on power
- Charge your cellphone, batteries, iPod and digital devices
- Flashlight function

Powerchimp is the lightweight portable charger that fits in your pocket to power up your devices day to day or in an emergency. Supplied with two rechargeable AA batteries, powerchimp puts up to 48 hours of instant power at your fingertips, ready when you need it most.

Powerchimp is developed with a safety feature to protect against overcharging. Easy to use, one button technology in a tough casing makes this the portable charger to take everywhere.

- Compatible with standard cellphones (including Nokia and Mini-Nokia, LG Chocolate, Samsung, Siemens, Sony Ericsson and Motorola) and other digital devices
- Pulse Charging technology ensures long battery life
- Soft touch one button technology - Auto Lock when charging or recharging
- Incorrect battery polarity protection - unit will not operate if you insert batteries incorrectly
- 2 AA Powertraveller long shelf life Ni-MH rechargeable batteries included for up to 48 hours extra power
- Standard AA batteries can be used but will not charge

Use powerchimp to power up these devices:

- Cellphones - approx 48 hours standby time and 4 hours talk time
- iPod - approx 20 hours; 4 hours if watching video
- AA rechargeable batteries - charge in approx 2 hours
- MP3/MP4s - approx 3 hours
- PSPs - approx 2.5 hours
- PDAs - approx 24 hours

Note: actual times will vary according to charge in the batteries and quality of batteries used.

Important: Due to the possible length of time between the manufacturing and sale of the product, Powertraveller cannot guarantee the actual state of charge left in the Powerchimp. Before you use your Powerchimp for the first time, charge it fully for 12 hours. Always use the same type of rechargeable batteries.

Instructions

To charge device:

1. Switch on by depressing the black button twice until LED flashes green
2. Connect to device you want to charge by attaching correct tip. If the tip you need is not included in this pack, visit www.powertraveller.com
3. Attach tip to charging cable
4. Connect charging cable to your device through its standard charging socket
5. Undo soft cover from top of powerchimp input socket and connect cable
 - LED green flashing light indicates charging; Powerchimp turns itself off 2 minutes after fully charged
 - LED flashing red light means unit needs charging



Each Pack Contains:

- 1 x Powerchimp 1
- 1 x Carry case 2
- 1 x DC3.5 x 1.1mm (0.14"x0.04") charging cable 3
- 1 x Retractable USB charging cable 4
- 2 x AA 1800mAh rechargeable batteries 5
- 1 x iPod tip (colour may vary) 6
- 1 x Samsung E900 tip 7
- 1 x Mini USB 9
- 1 x Female USB 11
- 1 x DC4.0 PSP tip 13
- 1 x Motorola V66 tip 8
- 1 x Sony Ericsson tip 10
- 1 x LG Chocolate tip 12
- 1 x Mini Nokia tip 14

To recharge your powerchimp:

- Flashing red light means unit needs recharging
- Fully charge your powerchimp from the USB on your laptop in 5 hours
- Plug tip of retractable USB charging cable into USB port of your laptop or other USB socket
- Plug other tip into powerchimp input socket
- LED is red when charging; LED turns green when fully charged
- May also be charged via mains and solar power

Specifications:

Capacity:	3600mAh
Input Interface:	DC3.5 x 1.1mm (0.14"x0.04")
Input Voltage:	4.5-5.5V
Input Current:	500mA
Output Interface:	DC3.5 x 1.1mm (0.14"x0.04")
Output Voltage:	5.5V
Output Current:	450mA Max
Weight:	20g (0.044lbs) + batteries
Dimensions:	92x40x24mm (3.62"x1.57"x0.94")
Colour:	grey, yellow, blue or pink (see pack)
Material:	rubber coated VO flame retardant ABS



iPod is a trademark of Apple Inc., registered in the U.S. and other countries



MADE IN CHINA

For customer support, please email: support@powertraveller.com

Powertraveller Ltd, 8 Delta Park, Wilsom Road, Alton, Hampshire, GU34 2RQ, UK

Tel: +44 (0) 1420 542980